

IT-FL45-SP

Ethernet Surge Protector

INTRODUCTION:

IEC61000-4-5 and ITU-TK20&K21 are the recognized standards for top quality surge protectors, IT-FL45-SP made by the high response surge arresters, the advantage allow clamping voltage and low loss against high speed signal, because it had a low capacitance. Designed to protect data communication lines in local and wide area networks up to 100Base-T transmission speeds.

PACKING LIST:

IT-FL45-SP is shipped with following items.

- 1. IT-FL45-SP×1
- 2. User manual ×1

FEATURES:

- 1. IEC6 1000-4-5 and ITU-TK20&K21
- 2. The high response surge arresters
- 3. Clamping voltage and low loss against high speed signal
- 4. Designed by theory of current limited and voltage clamped, discharged to ground
- 5. Standard:10Base-T/100Base-TX




SPECIFICATIONS:

Standard: 10Base-T/100Base-T standard 10/100M signal: IEC6100-4-5 and ITU-TK20&21 Nominal discharge current (In):5 KA (8/20µS) Working voltage: 0-5V Limit voltage: ≤40V Apply Band rate: 100Mbps Connector: RJ45 (F) The line of protection: 4 lines (1, 2, 3, 6)Insert consumption: ≤0.5dB Delay time: ≤1ns Working temperature:-20 to 60°C Storage temperature:-25 to 85°C Humidity: Relative humidity 5% to 95% No power supply needed, No consumption L×W×H: 72mm×42mm×25mm Shell: Alnico Color: Blue Weight: 10g Warranty: 5 years Approvals: FCC, CE, RoHS approvals

CIRCUIT DIAGRAM:

IT-FL45-SP is designed by the theory of current limited and voltage clamped, discharged to ground. When the data line exist surge, the IT-FL45-SP is induced and worked ,the lightning energy is discharged to ground, and the high surge voltage is clamped to low level, so our devices is protected.





APPLICATIONS:

Usually the IT-FL45-SP is used in protecting the following devices:


- 1 .Ether net Exchanger
- 2 .Ether net HUB
- 3 .Router
- 4 .Computer
- 5 .Indus trial control devices
- 6 .Net server for Video system

CAUTIONS AND NOTICES:

- 1. When installing the IT-FL45-SP to the end system, all equipment of en60950-1:2001 must be fulfilled.
- The IT-FL45-SP is connected by series mode, the port of IN is connected to outline, and the port of OUT is connected to the protected device. The IT-FL45-SP need connect to GROUND, and keep enough low resistance.
- 3. No special maintenance needed except for periodic inspection for looseness.
- If the circuit is open or short, it means The IT-FL45-SP has a fault and need to be replaced immediately.



DIMENSION:



CERTIFICATIONS:

